

**THE PROCESS OF OPENING THE PACKAGING**



Before opening the packaging, check the »shock sensor«, located on the outside of the packaging. If the indicator is coloured bright red, DO NOT OPEN THE PACKAGING, but immediately inform your transport agent!




1. Find the serial number written on the front side of the cardboard box



2. Cut the fixative strips off and remove cover of the cardboard packaging



3. Take out items enclosed with the oven (User Manual, packing list, test report, accessories, special orders...).



4. Remove top foam inserts.
5. Pull cardboard and foam inserts over the machine and set it down.
6. Take the oven out of the packaging and remove the plastic bag.
7. Read installation instructions.

After removing the packaging inspect the general state of the device and equipment, and check the accordance of the forwarded package with the enclosed packaging certificate. In the event of damage immediately inform the transport agent.



For further instructions see chapter 6. INSTALLATION in the USER MANUAL!